


## Assembly Instructions for #1501 TV Security Mount



Designed for use with LG Models: (compatible with both the 4 & 5 series)  
37LC5DC/S & 32LC5DC/S 37LC50C & 32LC50C

The #1501 TV Security Mount is typically used with granite or wood surfaces that have been predrilled to accept this Security Mount. If there are no preexisting holes, a template will need to be created. The template should have four 3/4" diameter holes. The hole centers on the template should match the location of the threaded studs on the bottom of the Security Mount. Hole centers are 8" by 4". The template should be positioned on the furniture top in the desired location of the TV. Once the holes are drilled, proceed with the mounting instructions below:

1. Carefully turn TV onto it's side. Attach the Security Mount to the base of the TV using the four **M5 x 12mm bolts**. Note: These four screw holes are counter sunk. Mount so that the bolt sits flush in the hole and the four internal stand-off's extend downward away from the TV.
2. Carefully place the television and security mount on the dresser top. The four internally threaded stand-off's should extend towards the bottom of the dresser top, through the previously drilled holes.
3. Using the **Security Driver**, install the **Washers** and the appropriate size **Pin-In-Head Button Security Screws** for your table top into each of the internally threaded stand-off's. **Note: Use 1-1/2" Pin-In-Head Button Security Screws for 1-1/2" material thickness and use 3" Pin-In-Head Button Security Screws for 3" material thickness.** The Television is now secure.


8901 Kelso Drive  
Baltimore, MD 21221  
Office: 410-918-1200  
Fax: 410-918-0964

Questions? Dial 888-4EDELLEN (888-433-3536) Ask  
for the Security Plate Team!

*Patent Pending*



*Assembly Instructions for #1501 TV Security Mount*



**Front**



M5 x 12 mm Bolt



Washer



T-27 Driver  
1/4 20 x2'' Pin-in-Head Security Screw  
1/4 20 x3'' Pin-in-Head Security Screw

8901 Kelso Drive  
Baltimore, MD 21221  
Office: 410-918-1200  
Fax: 410-918-0964

*Patent Pending*



*Assembly Instructions for #1501 TV Security Mount*



**Note: bottom of plate is shown**

8901 Kelso Drive  
Baltimore, MD 21221  
Office: 410-918-1200  
Fax: 410-918-0964

*Patent Pending*

